



FinishPro® 32

16 ga. Finish Nailer

Parts Reference Guide

**Guía de referencia
de piezas**

**Pièces Guide
de référence**



Schematic Drawings Inside
Plano esquemático en el interior
Schéma intérieur

Repair Kit
YK0394

SENCO®









Senco Brands, Inc.
4270 Ivy Pointe Blvd.
Cincinnati, OH 45245
1-800-543-4596
www.senco.com

NFG01X • Revised March 20, 2018 (Replaces 4/9/2015)

Questions? Comments? call SENCO's toll-free Action-Line: 1-800-543-4596
(North and South America Only) or email: toolprof@senco.com


¿Tiene preguntas? ¿Comentarios? Llame a la línea gratuita de acción de Senco: 1-800-543-4596
(sólo para América del Norte y del Sur) o envíe un correo electrónico: toolprof@senco.com

Des questions? Des commentaires? Communiquez avec le service d'assistance sans frais de Senco: 1-800-543-4596
(Amérique du Nord et Amérique du Sud seulement) ou envoyez un courriel: toolprof@senco.com




	Old Style	New Style
1	FC0490	FC0486
2	HA0154	HA0153
3	FA0238	FA0237
4	GC0937	GC0936
5	FC0491	FC0487
6	EA0156	EA0166
7	Single Sequential HB0306 HB0304	
	Contact Actuation HB0305 HB0303	

16 ga. Finish Nailer



Tool #	Model	A		B
		Old Style	New Style	
1X0201N	Single Sequential	GA0453	GA0510	HG0180
1X2201N	Single Sequential	GA0454	GA0511	HG0181
1X2202N	Contact Actuation	GA0454	GA0511	HG0181
1X3201N	Single Sequential	GA0453	GA0510	HG0180
1X3202N	Contact Actuation	GA0453	GA0510	HG0180

Magazine style is determined by style of safety element (Item ②)



REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • LISTE DE PIÈCES DE RECHANGE

Part No.	Description	Descripción	Désignation
AB0087	Belt Hook	Gancho De Cinturón	Crochet De Ceinture
BA0154	Deflector Assembly	Asamble De Desviador	Ensemble Déflecteur
BA0155	Firing Valve Assembly	Asamble De Válvula	Ensemble Valve
BA0156	Sleeve, Cylinder Assembly	Asamble De Cilindro	Ensemble Cylindre
BA0157	Cap Assembly	Asamble De Tapa	Ensemble Bouchon
BC0392	Retainer	Junta Tórica	Retenue
BC0393	Seal	Sello	Joint
BC0417	Muffler	Silenciador	Silencieux
BC0418	Piston Stop	Amortiguador	Amortisseur
BC0419	Spacer	Arandela	Rondelle
BC0420	Spacer	Arandela	Rondelle
BF0246	Firing Valve Washer	Arandela	Rondelle
CB0038	Trigger Valve Assembly	Asamble De Válvula	Valve D'Assemblée
EA0156	Piston Assembly	Asamble De Piston	Ensemble Piston-Couteau
EA0166	Piston Assembly	Asamble De Piston	Ensemble Piston-Couteau
FA0237	Front Plate Assembly	Asamble De Placa De Nariz	Ensemble Front
FA0238	Front Plate Assembly	Asamble De Placa De Nariz	Ensemble Front
FB0144	Latch Assembly	Asamble De Uñeta	Doigt De Retenue
FC0486	Driver Seal	Sello	Joint
FC0487	Guidebody	Guía	Guide
FC0488	Latch Assembly	Asamble De Uñeta	Doigt De Retenue
FC0490	Driver Seal	Sello	Joint
FC0491	Guidebody	Guía	Guide
GA0453	Magazine (US-Old Style)	Cargador	Magasin
GA0454	Magazine (EU-Old Style)	Cargador	Magasin
GA0455	Feeder Shoe Assembly	Asamble De Alimentador	Ensemble Poussoir
GA0456	End Cap Assembly	Asamble De Tapa Terminal	Bouchon D'Extrémité De Rail
GA0510	Magazine (US-New Style)	Cargador	Magasin
GA0511	Magazine (EU-New Style)	Cargador	Magasin
GA0679	Feeder Spring Assembly	Asamble De Alimentador	Ensemble Poussoir
GC0901	Wheel Guide	Guía	Guide
GC0934	Plate	Placa	Plaque
GC0935	Magazine Support	Soporte	Cavalier
GC0936	Cover	Cubierta	Couvercle
GC0937	Cover	Cubierta	Couvercle
HA0153	Safety Element Assembly	Asamble De Seguro	Ensemble Palpeur De Sécurité
HA0154	Safety Element Assembly	Asamble De Seguro	Ensemble Palpeur De Sécurité
HB0303	Trigger Assembly (Contact Actuation)	Asamble De Gatillo	Ensemble Gâchette
HB0304	Trigger Assembly (Single Sequential)	Asamble De Gatillo	Ensemble Gâchette
HB0305	Trigger Assembly (Contact Actuation)	Asamble De Gatillo	Ensemble Gâchette
HB0306	Trigger Assembly (Single Sequential)	Asamble De Gatillo	Ensemble Gâchette
HC0382	Pin	Pasador	Goupille
HC0395	Spring Retainer	Junta Tórica	Retenue
HC0396	No-Mar Pad	Amortiguador	Coussin
HC0401	No-Mar Pad	Amortiguador	Coussin
HG0180	Safety Label (US)	Etiqueta	Étiquette
HG0181	Safety Label (EU)	Etiqueta	Étiquette
KB0020	Screw	Tornillo	Vis
KB2968	Washer	Arandela	Rondelle
KB3588	Screw	Tornillo	Vis
KB3589	Screw	Tornillo	Vis
KB3590	Screw	Tornillo	Vis
KB3591	Screw	Tornillo	Vis
KB3592	Washer	Arandela	Rondelle
KB3593	Pin	Pasador	Goupille
KB3594	Pin	Pasador	Goupille
KB3595	Pin	Pasador	Goupille
KB4357	Feeder Spring	Resorte	Ressort
KB4359	Spring	Resorte	Ressort
KB4360	Spring	Resorte	Ressort
KB9825	Screw	Tornillo	Vis
KB9826	Screw	Tornillo	Vis
KB9832	Screw	Tornillo	Vis
KB9837	Nut	Tuerca	Écrou
KB9838	Washer	Arandela	Rondelle
KB9839	Washer	Arandela	Rondelle
KC0062	Retainer	Junta Tórica	Retenue
LB0965	Seal	Sello	Joint
LB0968	Seal	Sello	Joint
LB0970	Gasket	Sello	Joint
LB0971	Gasket	Sello	Joint
PC0479	Air Fitting	Conexión De Aire	Raccord Air