

## DuraSpin® ACCESSORIES

### Phillips #2 Screw Bits



One Piece Bit (2 pack)	Item #
Fits DS200-14V, DS162-14V	EA0122
Fits DS200, DS200-S4, DS200-S2	EA0124
Fits DS300, DS300-S2, DS300-S4	EA0128



Replacement Tips (5 pack)	Item #
DS300-AC, DS275-18V, DS202-14V DS205-14V	EA0142

### Square #2 Screw Bits



One Piece Bit (2 pack)	Item #
Fits DS200-14V	EA0123
Fits DS200-S4, DS200, DS200-S2	EA0125
Fits DS300-S4, DS300-S2, DS300	EA0127
Fits DS300-AC, DS300-24V (not packaged)	EA0141



Replacement Tips (5 pack)	Item #
DS300-AC, DS275-18V, DS202-14V DS205-14V	EA0143

### Flooring Extension



Description	Item #
Fits DS200, DS300	WB0002

Attaches to screw gun and DuraSpin attachments to allow you to drive screws from a comfortable standing position.

## BATTERIES AND CHARGERS



Description	Item #
12V (2.0AH) Battery Fits AirFree® 25	VB0022



14.4V (2.0Ah) Battery Fits AirFree 41, DS202-14V, DS205-14V	VB0023
--	--------



18V (2.0Ah) Battery Fits DS275-18V	VB0036
---------------------------------------	--------



24V (2.0AH) Battery Fits DS300-24V	VB0037
---------------------------------------	--------



9.6V-24V Battery Charger For VB0022, VB0023, VB0036 & VB0037	VB0002
---	--------



Description	Item #
14.4V(1.7Ah) Stem Battery Fits DS200-14V, DS162-14V, SS-14V	VC0011



14.4V One Hour Stem Battery Charger For use with VB0011 battery	VB0004
--	--------