

# SFT10XP-A-DL

## Auto Double Length Fine Wire Stapler

Parts Reference Guide  
Guía de referencia  
de piezas  
Pièces Guide  
de référence



**Repair Kit**  
YK0802  
YK0804



Schematic Drawings Inside  
Plano esquemático en el interior  
Schéma intérieur



**NFG06S-A-DL • January 30, 2023 (Replaces 1/26/19)**

KYOCERA-SENCOR Industrial Tools, Inc.  
8450 Broadwell Road  
Cincinnati, OH 45244  
1-800-543-4596  
www.senco.com






Questions? Comments? call SENCOR's toll-free Action-Line: 1-800-543-4596  
(North and South America Only) or email: [toolprof@senco.com](mailto:toolprof@senco.com)

¿Tiene preguntas? ¿Comentarios? Llame a la línea gratuita de acción de Senco: 1-800-543-4596  
(sólo para América del Norte y del Sur) o envíe un correo electrónico: [toolprof@senco.com](mailto:toolprof@senco.com)

Des questions? Des commentaires? Communiquez avec le service d'assistance sans frais de Senco : 1-800-543-4596  
(Amérique du Nord et Amérique du Sud seulement) ou envoyez un courriel: [toolprof@senco.com](mailto:toolprof@senco.com)




# Contents of YK0802 Kit  
 ## Contents of YK0804 Kit



HA0258





**Tool #**

6S0311N B WIRE (US)	6S2361N AT (EU)
6S0321N C WIRE (US)	6S2321N C (EU)
6S0341N F WIRE (US)	6S2341N F (EU)
6S0351N G WIRE (US)	6S2351N G (EU)
6S0361N H WIRE (US)	



Model	(A)	(B)	(C)	(D)	(E)
AT	EA0256	FA0296	GA0598	GC1392	GA0599
B	EA0245	FA0286	GA0594	GC1392	GA0586
C	EA0244	FA0284	GA0579	GC1359	GA0583
F (US)	EA0248	FA0291	GA0594	GC1392	GA0586
F (EU)	EA0283	FA0291	GA0594	GC1392	GA0586
G	EA0251	FA0293	GA0579	GC1359	GA0583
H	EA0249	FA0290	GA0595	GC1361	GA0587

**Available Plugs**  
(Not Included with Tool)

	PC0479 ✓
1/4" Body	Ind. Interchange 1/4" NPT
	PC0486
3/8" Body	Ind. Interchange 1/4" NPT
	PC0468 ✓
1/4" Body	Tru-Flate 1/4" NPT
	PC0474
3/8" Body	Tru-Flate 1/4" NPT

✓ **Recommended Plugs**  
Plugs shown smaller than actual size

**REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • LISTE DE PIÈCES DE RECHANGE**

PART NO.	DESCRIPTION	DESCRIPCIÓN	DÉSIGNATION
AA0189	CAP ASY	TAPA	BOUCHON
AA0192	CAP ASY	TAPA	BOUCHON
AC0503	MAINBODY	CARCASA	CORPS
AC0506	MUFFLER	SILENCIADOR	SILENCIEUX
AC0508	RETAINER	RETÉN	RETENUE
BC0819	CYLINDER SLEEVE	CILINDRO	CYLINDRE
BC0820	BUMPER	AMORTIGUADOR	AMORTISSEUR
BC0864	VALVE	VÁLVULA	VALVE
CA0133	VALVE ASY	VÁLVULA	VALVE
CA0139	VALVE ASY	VÁLVULA	VALVE
CA0140	VALVING ASY	VÁLVULA	VALVE
EA0244	PISTON DRIVER ASY (C)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0245	PISTON DRIVER ASY (B)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0248	PISTON DRIVER ASY (F)(US)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0249	PISTON DRIVER ASY (H)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0251	PISTON DRIVER ASY (G)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0256	PISTON DRIVER ASY (AT)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
EA0283	PISTON DRIVER ASY (F)(EU)	PISTÓN/ACCIONADOR	PISTON/MOTEUR
FA0284	FRONT PLATE ASY (C)	PLACA	PLAQUE
FA0286	FRONT PLATE ASY (B)	PLACA	PLAQUE
FA0290	FRONT PLATE ASY (H)	PLACA	PLAQUE
FA0291	FRONT PLATE ASY (F)	PLACA	PLAQUE
FA0293	FRONT PLATE ASY (G)	PLACA	PLAQUE
FA0296	FRONT PLATE ASY (AT)	PLACA	PLAQUE
GA0579	RAIL ASY (C,G)	ASAMBLE DE CARRIL	RAIL D'ASSEMBLÉE
GA0583	MAGAZINE ASY (C,G)	ASAMBLE DE CARGADOR	MAGASIN D'ASSEMBLÉE
GA0586	MAGAZINE ASY (B,F)	ASAMBLE DE CARGADOR	MAGASIN D'ASSEMBLÉE
GA0587	MAGAZINE ASY (H)	ASAMBLE DE CARGADOR	MAGASIN D'ASSEMBLÉE
GA0594	RAIL ASY (B,F)	ASAMBLE DE CARRIL	RAIL D'ASSEMBLÉE
GA0595	RAIL ASY (H)	ASAMBLE DE CARRIL	RAIL D'ASSEMBLÉE
GA0598	RAIL ASY (AT)	ASAMBLE DE CARRIL	RAIL D'ASSEMBLÉE
GA0599	MAGAZINE ASY (AT)	ASAMBLE DE CARGADOR	MAGASIN D'ASSEMBLÉE
GC1359	FEEDER SHOE (C,G)	ALIMENTADOR	POUSSOIR
GC1361	FEEDER SHOE (H)	ALIMENTADOR	POUSSOIR
GC1392	FEEDER SHOE (AT,B,F)	ALIMENTADOR	POUSSOIR
HA0258	TRIGGERING ASY	GATILLO	GÂCHETTE
HC0654	TRIGGER	GATILLO	GÂCHETTE
KB6841	SPRING	RESORTE	RESSORT
KB6844	SPRING	RESORTE	RESSORT
KB6847	NUT	TUERCA	ÉCROU
KB6849	WASHER	ARANDELA	RONDELLE
KB6851	PIN	PASADOR	GOUPILLE
KB6852	PIN	PASADOR	GOUPILLE
KB6862	SCREW	TORNILLO	VIS
KB6869	PIN	PASADOR	GOUPILLE
KB6865	SCREW	TORNILLO	VIS
KC0882	PIN	PASADOR	GOUPILLE
LB1250	O-RING	SELLO	JOINT
LB1253	O-RING	SELLO	JOINT
LB1258	O-RING	SELLO	JOINT
LB1261	O-RING	SELLO	JOINT
LB1262	O-RING	SELLO	JOINT
LB1291	O-RING	SELLO	JOINT
LB5147	O-RING	SELLO	JOINT