

REPLACEMENT PARTS LIST
 LISTA DE PARTES DE REPUESTO • LISTE DES PIÈCES DE RECHANGE

PART NO.	NOTES	DESCRIPTION	DESCRIPCIÓN	DÉSIGNATION
H0002		Handle	Mango	Poignée
H0013	quantity (4)	Screws/Washers	Tornillo/Arandela	Vis/Rondelle
H0020	includes band	Ratchet assembly	Asamble del retén	Rochet
H0033		Pins	Pasador	Tige de butée
H0036		Pins	Pasador	Goupilles
H0037		Screw	Tornillo	Vis
H0038		Driver	Percusor	Tige de poussée
H0045		Spring	Muelle	Ressort
H0055		Feeder shoe assembly	Asamble de alimentador	Coulisseau
H0080		Hammer	Martillo	Marteau
H0084		Cap	Tapa	Caoutchouc
H0085		Replacement band	Goma	Élastique de rechange
H0087		Block	Bloque	Bloc
H0108		Plastic base	Base de plástico	Semelle
H0119		Plunger	Émbolo	Piston
H0130		Guide	Guía	Guide
H0144		Plate	Placa	Plaque
H0150	includes H0055	Magazine	Cargador	Magasin
H0158		Retainer	Junta tórica	Caoutchouc de retenue
H0188	optional accessory	Plastic base for ½" flooring	Base plástico	Semelle pour planches de ½"
H0343		Guide body	Placa de nariz	Plaque guide
P0154		Grip	Agarradero	Gaine
H0922		Ratchet pin assembly	Pasador del retén	Axe du rochet

In the U.S.A., you will find your nearest Senco location listed in the Yellow Pages under "Staples".
 Or, you can call our toll-free Action-line: 1-800-543-4596

H0878; Revised March 30, 2006 (Replaces May 1, 1999) © 1999, 2006 Senco Products Inc., Cincinnati, Ohio 45244 - USA

SENCO

SHF15

